



*University of California,
Los Angeles*

Copy right 2000-2007 Michael K. Stenstrom

Fine Pore Aeration Systems Testing

Michael K. Stenstrom
**Professor, Civil and Environmental
Engineering Department**



Fine Pore Diffusers

- Fine pore aeration systems are the most energy conserving alternative we have for the activated sludge process, and may other applications
- **Well established technology and design principles**
- Nevertheless, we have had many technology failures
- **Proper utilization of the technology requires a commitment to maintenance**



Outline

- **Terminology**
- **Off-gas testing**
- **Materials testing**
- **Some conclusions**



Terminology

- **Efficiency**
 - **Standard oxygen transfer efficiency (SOTE) (percent oxygen transferred)**
 - **Standard oxygen transfer rate (SOTR) (mass transferred per unit time)**
 - **Standard aeration efficiency (SAE) (mass transferred per unit time per unit power)**



Terminology Cont.

- SOTE - percent
- SOTR – lb O₂/hr or kg O₂/hr
- SAE – lb O₂/hp-hr or kg O₂/kW-hr
- **All above at standard conditions (e.g. 20°C, clean water, etc.)**
- OTE, OTR, AE – at process conditions



Standard and Process Conditions

- Correction formulas based upon driving force, temperature, barometric pressure, water quality, saturation concentration, etc
- Driving force and water quality the most significant
- Driving force = $(DO_s - DO)/DO_s$
- Water quality – alpha factor, 0 to 1
- Total correction can result in process water transfer of only 30 to 80% of clean water transfer




Off-Gas Testing

- Accepted as the best way to do process water testing of diffused aeration systems
- Used to the exclusion of almost all other methods for diffused systems
- Provides reliable indication of aeration efficiency, air flow distribution, wastewater flow splits among parallel aeration tanks, diffuser aging
- Reliable in underloaded, critically loaded and overloaded treatment plants



Analyzer

Off-Gas Technique





The Mathematics

$$\begin{aligned} \text{OTE} &= \frac{\text{mass O}_2 \text{ in} - \text{mass O}_2 \text{ out}}{\text{mass O}_2 \text{ in}} \\ &= \frac{G_i (M_o / M_i) \text{MR}_{o/i} - G_i (M_o / M_i) \text{MR}_{og/i}}{G_i (M_o / M_i) \text{MR}_{o/i}} \\ &= \frac{\text{MR}_{o/i} - \text{MR}_{og/i}}{\text{MR}_{o/i}} \end{aligned}$$

Use the ratio of oxygen to inerts to remove gas flow rate from the calculation



Off-Gas Measurement

- Use a simple fuel cell to measure oxygen partial pressure
- Ambient air for calibration of mole ratio
- Remove moisture and CO_2 to simplify the procedure
- Measure off-gas and compare to ambient air



Measuring Air Flow Rate

- Not needed for OTE measurement
- Useful to create an average of a large basin
- Needed to calculate the oxygen uptake rate, or total mass transferred
- Measure discharge from hood by establishing a stable pressure under the hood



*University of California,
Los Angeles*


Off-Gas Analyzer

Rotometer

Manometers

Fuel Cell

Vacuum Cleaner





*University of California,
Los Angeles*

Copy right 2000-2007 Michael K. Stenstrom

Off-Gas Hood






Analyzer in Action





*University of California,
Los Angeles*

Small Hoods






Large Hoods



96 5 30



Really Large Hoods





*University of California,
Los Angeles*

Coarse Bubble Hoods

Sand Bags

Testing in a turbulent
spiral roll system
requires a heavy hood
and weights






Off-Gas Results

- **Define aeration capacity**
- **Track aerator performance and “health”**
- **Better understand process conditions**
- **Define key process parameters for expansion**
- **Warranty Opportunities**




Typical Results






A Tale of Two Tanks






Transfer Efficiency and Pressure Drop

In a small tank, one can test pressure drop, oxygen transfer efficiency and observe flow patterns








*University of California,
Los Angeles*


Copy right 2000-2007 Michael K. Stenstrom

Special Holders for Membranes





Decrease in Pressure Drop With Acid Cleaning






University of
Los Angeles

Field Pressure Drop Device





Typical Results Pressure Drop





Pool Flow Distribution






Evaluating Membrane Hardness and Strength




Durometer



Pin penetrates surface as a function of hardness



Small Test Frame




Force

Membrane "Dog Bone"

Displacement



Load Cell on Test Frame



Load Cell



Thickness

Pressure gage for repeatable measurements





University of California,
Los Angeles


Measuring Orifice Diameters

Pin inserts into an orifice a
fixed distance as a
function of its diameter







Change in Modulus weakening with age





Microscopic Examination

(Polyurethane Membrane)



Microscopic Examination

(Sintered Plastic)






*University of California
Los Angeles*

Microscopic Examination

(EPDM Membrane)


Used

New







Silicone Membranes



Membrane Surface



Pore Close Up



Pore Side View

From Wiehe and Libra (2004)



Conclusions

- It is easy to track fine pore aeration system performance with off-gas testing
- One or two days every few months gives a “health” report of the aeration system. Initial and periodic testing give good information for design
- Lab-scale testing for material properties and sources of fouling can predict failures or help you understand why membranes failed
- A small, but routine investment in testing is needed
- Must plan – cannot just decide to go out and test. Diffusers must be observed over time to detect changes in efficiency or properties